

# **BINKS** PROPORTIONING PUMP - used on Epoxy trucks.

- 1. 41-12534 - SOLVENT CUP
- 2. 41-12547 - UPPER PACKING NUT
- 6. 109-852 - UPPER PUMP TUBE ASSEMBLY
- 7. 41-12573 - PUMP ROD
- 11. 41-12556 - LOWER PACKING NUT ASSEMBLY
- 12. 41-12555 - TUBE SEAL
- 13. 41-12552 - PIN
- 14. 41-12570 - UPPER BALL CAGE
- 15. 41-12568 - UPPER SEAT RETAINER ASSEMBLY
- 16. 41-12567 - SEAL - UPPER SEAT ASSEMBLY TO PISTON ROD
- 17. 41-12558 - LOWER PUMP TUBE
- 18. 41-12559 - PIN
- 19. 41-12560 - LOWER BALL CAGE
- 20. 41-12561 - LOWER SEAT RETAINER ASSEMBLY
- 21. 41-12566 - SEAL - LOWER SEAT ASSEMBLY TO PISTON ROD
- 22. 41-12564 - SEAL - FOOT VALVE BODY TO LOWER TUBE
- 23. 41-12565 - FOOT VALVE BODY
- 24. 20-5017 - BALL 1 3/4 DIA.
- 25. 20-4962 - BALL 1 1/4 DIA.
- 26. 20-5412 - "O" RING 2 1/4 OD 2 1/6 ID
- 27. 41-12541 - FEMALE ADAPTER
- 28. 41-12635 - PACKING, LEATHER, UPPER (3)
- 29. 41-12544 - PACKING (TEFLON) UPPER (3)
- 30. 41-12540 - MALE ADAPTER
- 31. 41-12553 - MALE ADAPTER
- 32. 41-12571 - BACKING (TEFLON) LOWER (3)
- 33. 41-12638 - PACKING, LEATHER, LOWER (3)

Carbide seat

